



Driving Range

Thank you for purchasing actionXL's new motion-controlled Driving Range game. We are excited that you have chosen to become a part of the motion in gaming revolution, and that you have chosen the actionXL controller.

In order to play you will need an actionXL motion controller (wired or wireless), and a computer running either Windows Vista or Windows XP, with at least 1 open USB port.

Made-for-Motion™ presents

ACTIONXL DRIVING RANGE

Made Exclusively for the
ActionXL Motion Controllers!



Fiihand wireless
motion controller



Wired motion
controller



Driving Range	1
Installing your game	2
Installing from the actionXL website	2
Activating to the Full Version (requires Internet connection)	2
Installing from a CD	2
The Main Menu	2
Single Player	3
Head to Head	3
Play with Skype	3
Select Character	3
Hitting the Ball	3
End of Game	3
Customer Support	3

Installing your game

Installing from the actionXL website

Download the free trial version from the actionXL website. You can choose to Save or Run the game. If you choose Run, simply select the default options during installation. Once the installation finishes, a game icon should appear on your desktop.

If you choose to Save the game, once the game finishes downloading, go to the folder you downloaded the game to. Double click the exe file that you downloaded. Select the default options during installation. Once the installation finishes, a game icon should appear on your desktop.

Activating to the Full Version (requires Internet connection)

If you do not have an activation key yet, use the left button to click on the Unlock icon in the Main Menu, and then click on the Buy Now icon. Once you have completed your purchase through the Kagi Store secure server, an activation code will be sent to you.

To activate your copy of Driving Range and unlock all of the features, use the left button to click on the Unlock icon in the Main Menu, and then click on the Activate Now icon. When activating, you will be asked to create a password. Use a password that is easy to remember. You will need this password if you ever have to reinstall Driving Range on your computer.

Installing from a CD

The CD should start running after you insert it into your CD/DVD drive. If it doesn't run automatically, the CD may be damaged. Call actionXL customer support and we will help you start program manually. If the CD is damaged, we will replace it and make every effort to help you get the game installed.

The Main Menu

Use your controller to control the main menu. Tilting left or right will turn the menu wheel left and right. When the selection you want is at the top of the wheel, click the left button to choose it.



Single Player

This is your practice mode. This is the only playing mode available on the free demo version.

Head to Head

If you want to play against someone, choose Head to Head mode. You can either plug in a second controller, or share a single controller.

Play with Skype

If you want to play against one of your friends across the Internet, use the Play with Skype mode. Both you and your friend must have Skype installed on your computers to use this mode.

This product uses the Skype API but is not endorsed, certified or otherwise approved in any way by Skype. This game uses Skype app2app connections to transmit game data when playing with Skype, initiates outgoing calls when attempting to connect to a member of your buddy list, and listens for incoming calls while in the Skype menu.

Select Character

This menu option allows you to build, name, and save a character. Choose skin and hair color, hair style, shirt color, and pants color. Then name your character and save it.

Hitting the Ball

- Swing your Motion Controller the way you would swing a golf club. The harder you swing, the farther your ball will go.
- If you twist your Motion Controller while you are swinging it, the ball will slice or hook.
- The farther you drive the ball, the more points you earn.
- You can earn extra points by hitting a target.

End of Game

At the end of the game, clicking the left button will start a new game. Clicking the right button will return you to the main menu.

Customer Support

Phone: 480-575-0719 Monday through Friday 8am to 6pm PST

Email: support@actionxl.com

Web Site: <http://www.actionxl.com>